

US TV Channel Number vs. Frequency

VHF TELEVISION FREQUENCIES

BAND	CH #	FREQUENCY	BAND	CH #	FREQUENCY
VHF LOW	02	54-60 Mhz	VHF HIGH	07	174-180 Mhz
VHF LOW	03	60-66 Mhz	VHF HIGH	08	180-186 Mhz
VHF LOW	04	66-72 Mhz	VHF HIGH	09	186-192 Mhz
VHF LOW	05	76-82 Mhz	VHF HIGH	10	192-198 Mhz
VHF LOW	06	82-88 Mhz	VHF HIGH	11	198-204 Mhz
		VHF HIGH	12	204-210 Mhz	
		VHF HIGH	13	210-216 Mhz	

UHF TELEVISION FREQUENCIES

CH #	FREQUENCY	CH #	FREQUENCY	CH #	FREQUENCY
14	470-476 Mhz	38	614-620 Mhz	62	758-764 Mhz
15	476-482 Mhz	39	620-626 Mhz	63	764-770 Mhz
17	488-494 Mhz	41	632-638 Mhz	65	776-782 Mhz
18	494-500 Mhz	42	638-644 Mhz	66	782-788 Mhz
19	500-506 Mhz	43	644-650 Mhz	67	788-794 Mhz
20	506-512 Mhz	44	650-656 Mhz	68	794-800 Mhz
22	518-524 Mhz	46	662-668 Mhz		
23	524-530 Mhz	47	668-674 Mhz		
24	530-536 Mhz	48	674-680 Mhz		
25	536-542 Mhz	49	680-686 Mhz		
26	542-548 Mhz	50	686-692 Mhz		
27	548-554 Mhz	51	692-698 Mhz		
28	554-560 Mhz	52	698-704 Mhz		
29	560-566 Mhz	53	704-710 Mhz		
30	566-572 Mhz	54	710-716 Mhz		
31	572-578 Mhz	55	716-722 Mhz		
32	578-584 Mhz	56	722-728 Mhz		
33	584-590 Mhz	57	728-734 Mhz		
34	590-596 Mhz	58	734-740 Mhz		
35	596-602 Mhz	59	740-746 Mhz		
36	602-608 Mhz	60	746-752 Mhz		
37	608-614 Mhz	61	752-758 Mhz		